


Counter bore 2.50", 0.10" with step at 2.01", 0.45".

Depth is @ 0.55" to end up with a wall @0.13".

Use 2" o.d. S.S. tube to surround connectors (2.00"o.d. x 1.875" i.d. x 2.25" long)

<b>Originator:</b> Walter Jaskierny <b>Drawn by:</b> Walter Jaskierny		 <b>Fermilab Particle Physics Division</b> <b>Site Support Group</b>		
		<b>Title</b> Purity Monitor Vacuum Feedthrough		
<b>Originated:</b> 12 May 2006 <b>Last Revision:</b> 16 May 2006	<b>Size</b> <b>A</b>	<b>FSCH No</b>	<b>DWG No</b>	<b>Rev</b> <b>B</b>
<b>Issued</b>	<b>Scale</b>	<b>Project</b> Flare	<b>Sheet</b> 1 of 1	